
-HV
E
to AMP, MCA & DAQ
Carrier Gas
Flow Direction
D
Electric Field
Direction
A
F
B
C